

FELLOW®

Carter™ Wide

SAFETY AND USE GUIDE

Please read this guide completely before using. Improper handling may result in product damage or an accident. Please keep this guide for future reference.

Proper use guidelines:



Dishwasher



Oven



Microwave

IMPORTANT SAFETY NOTES

Check your Carter to ensure that all pieces of products are accounted for and installed correctly. Do not use if parts are missing.

Do not use if you see signs of cracking, chipping, and any other abnormality.

Keep Carters holding hot beverages away from children and pets.

USE INSTRUCTIONS

Preparation before first use: Hand wash thoroughly with soap and a soft sponge.

Please pay attention when setting down. The Carter body is sturdy stainless steel but will dent if dropped on hard surfaces!

Carter is not microwave safe.

Do not use any metal stirring utensils in Carter. This will scratch the ceramic non-stick coating.

Do not let children use.

CLEANING AND MAINTENANCE:

Both Carter Wide Lid and Mug are dishwasher safe. However we recommend hand washing to preserve the coating.

For hand washing, use only liquid dish soap and a soft sponge. Using a coarse sponge, brush, or other rough surface will scratch the outer and interior surfaces of Carter. Do not use chlorine, bleach, or other chemicals to clean. Let air or towel dry thoroughly.

While not in use, store Carter with the lid off to prevent unwanted smells.

For more help head to:
help.fellowproducts.com

Fellow Industries Inc.
San Francisco, CA 94110
Patent: fellowproducts.com/patents
fellowproducts.com